



# Opening a Lockbox

## Using the Supra Mobile App as a Showing Agent with Appointment


1. Log into the Supra Mobile App.




2. From the agent dashboard (i.e., home screen), tap the *Showings* icon on the bottom menu.



3. Tap the confirmed showing to view showing details.



4. Scroll down until you see the *Open Lockbox* button. Tap the **Open Lockbox** button.



[suprasystems.com](https://suprasystems.com)


800-547-0252 • © 2025 Honeywell International Inc. Neither this document nor the information contained herein may be reproduced, used, distributed or disclosed to others without the written consent of Honeywell.

Rev. B

# Opening a Lockbox



## Using the Supra Mobile App as a Showing Agent with Appointment

5. Push up on the bottom of the BT LE lockbox to turn on Bluetooth® and then enter your PIN on the app.



(No need to push up on the bottom of Invoy lockboxes, other than to access key container.)

6. A screen will show the app connecting to the lockbox and then a “Ready to Open” screen appears. Push up on the bottom of the lockbox to access keys.



**Note:** The “Ready to Open” screen looks slightly different for Invoy lockboxes. Agents with shackle permissions can open the shackle as well as access the key container.



[suprasystems.com](https://suprasystems.com)

800-547-0252 • © 2025 Honeywell International Inc. Neither this document nor the information contained herein may be reproduced, used, distributed or disclosed to others without the written consent of Honeywell.

Rev. B